S70 SERIES

1 gang 1 way switch
1 gang 2 way switch

2 gang 1 way switch
2 gang 2 way switch

3 gang 1 way switch
3 gang 2 way switch

4 gang 1 way switch
4 gang 2 way switch

Doorbell switch

1gang 15A

1 gang 3 pin MF socket
with neon+USB+Type C

1 gang 15A socket

1 gang with 4 pins socket

1 gang 3 pin MF socket
+2USB
+Type C

2 pin socket

2 gang with 4 pins socket

4 pins socket

1 gang 5 pin MF socket

TV+TEL socket
TV+computer socket

1 gang with 2 pins socket

2 pin socket with TV

2 pin socket with TEL
2 pin socket with Int

5 pin MF socket

TV socket

TEL socket
Computer socket

Satellite+TV socket

Satellite+TEL socket
Satellite+computer socket

45A DP switch

25A DP switch

Touch switch

25A DP switch
45A DP switch

25A DP switch
45A DP switch

1 gang+Adjust speed

Adjust speed

Blank plate

Blank plate(3*6)

Big panel 4gang

Big panel 6gang

2 gang 3 pin MF socket

2 gang 3 pin MF socket +2USB

2 gang 3 pin MF socket+USB+Type C