

T63 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch



3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch




25A DP switch



Touch switch



1 gang 13A single pole
with neon
1 gang 13A double pole
with neon



1 gang 3 pin MF socket



1 gang 15A socket



1 gang 13A socket
+2USB



1 gang 3 pin MF socket
+2USB



Voice switch



Dimming



1gang + dimmer



1 gang + Adjust speed



Adjust speed




1 gang 13A socket with
neon+USB+Type C



1 gang 3 pin MF socket+
USB+Type C



13A socket



3 pin MF socket



USB+Type C



European socket




Schuko socket




25A DP switch
45A DP switch



25A DP switch
45A DP switch



Human body induction



1gang 15A



1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket



3 pin MF socket+2USB
+Type C



Blank plate




Blank plate(3*6)




Big panel 4gang



Big panel 6gang



2 pin socket




1 gang with 2 pins socket




2 pin socket with TV



2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



Cooker unit



2gang 13A single pole
2gang 13A double pole




2gang 13A socket +USB +TYPE C



2 gang 3 pin MF socket




4 pins socket



1 gang with 4 pins socket



2 gang with 4 pins socket



TV socket




TEL socket
Computer socket




2 gang 3 pin MF socket



2 gang 3 pin MF socket +2USB



2 gang 3 pin MF socket+USB+Type C




Double TV socket



TV+TEL socket
TV+computer socket



TEL+computer socket
Double TEL socket
Double computer socket



Satellite socket



Double satellite socket