

Q7 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch
2 gang 1 way switch
2 gang 2 way switch
3 gang 1 way switch
3 gang 2 way switch
4 gang 1 way switch
4 gang 2 way switch
Doorbell switch



1gang 15A
1 gang 3 pin MF socket with neon
1 gang 15A socket with neon
1 gang with 4 pins socket
1 gang 3 pin MF socket with neon+2USB




2 pin socket
1 gang 3 pin MF socket+USB+Type C
TV+TEL socket
TV+computer socket
3 pin MF socket
USB+Type C



4 pins socket
1 gang 13A socket with neon+USB+Type C
1 gang 3 pin MF socket
1 gang 5 pin MF socket with neon
3 pin MF socket+2USB+Type C



TEL socket
Computer socket
1 gang with 2 pins socket
2 pin socket with TV
2 pin socket with TEL
2 pin socket with Int
5 pin MF socket



2 gang with 4 pins socket
TV socket



Satellite+TV socket
Satellite+TEL socket
Satellite+computer socket
45A DP switch
25A DP switch
Touch switch



25A DP switch
45A DP switch
25A DP switch
45A DP switch
1gang + dimmer
1 gang+Adjust speed
Adjust speed



Blank plate
Blank plate(3*6)
Big panel 4gang
Big panel 6gang
2 gang 3 pin MF socket



2 gang 3 pin MF socket with neon
2 gang 3 pin MF socket with neon+2USB
2 gang 3 pin MF socket+USB+Type C with neon