

S16 SERIES

LIGHT SWITCHES A NEW WAY TO EXPERIENCE DESIGN AND FUNCTION



1 gang 1 way switch
1 gang 2 way switch




2 gang 1 way switch
2 gang 2 way switch




3 gang 1 way switch
3 gang 2 way switch



4 gang 1 way switch
4 gang 2 way switch



Doorbell switch



Satellite+TV socket



Satellite+TEL socket
Satellite+computer socket




45A DP switch



25A DP switch




Touch switch



1gang 15A



1 gang 3 pin MF socket



1 gang 15A socket




1 gang with 4 pins socket



1 gang 3 pin MF socket
+2USB



25A DP switch
45A DP switch



25A DP switch
45A DP switch




1gang + dimmer




1 gang+Adjust speed



Adjust speed




2 pin socket



1 gang 3 pin MF socket+
USB+Type C




2 gang with 4 pins socket




3 pin MF socket




USB+Type C




Blank plate




Blank plate(3*6)




Big panel 4gang



Big panel 6gang




4 pins socket




1 gang 13A socket
with neon+USB+Type C



1 gang 3 pin MF socket



1 gang 5 pin MF socket



3 pin MF socket+2USB
+Type C




2 gang 3 pin MF socket




2 gang 3 pin MF socket+2USB



2 gang 3 pin MF socket+USB+Type C



2 gang 3 pin MF socket



TV+TEL socket
TV+computer socket




1 gang with 2 pins socket




2 pin socket with TV




2 pin socket with TEL
2 pin socket with Int



5 pin MF socket



TV socket



TEL socket
Computer socket